

RETRACT HANDLE MOD.

"T" HANDLE ADDITION
MAKES TRANSITION FROM "DOWN"
TO "UP" MUCH EASIER.

SLOTTED
TUBE GUIDE IS EASIER TO
MAKE & CANNOT COME APART
DUE TO VIBRATION ECT.

